

**Willhoit Auto Restoration
1360 Gladys Ave
Long Beach, CA 90804
Tel. (562) 439-3333**

WR Lightweight Flywheel and Clutch Package

ASSEMBLY INSTRUCTIONS:

The flywheel and pressure plate have been individually balanced. It is recommended when building an engine that the crankshaft, flywheel and pressure plate be balanced as a unit.

Torque pressure plate hex bolts to 35lbs.

Use a small amount of anti-seize on the flywheel glandnut and torque to 450lbs.

For high performance applications, eliminate the factory iron gasket and seal the flywheel to crankshaft mating surface with a small amount of high temp sealant such as Curil T (the end play will need to be adjusted w/o the iron gasket).